THELEMA URBAN 80

USER MANUAL

SAFETY WARNINGS

1. Warning for vulnerable consumer groups:
2. Battery Caution:
3. Tank Attention:
4. Warranty:
5. Contacts:

MAIN FEATURE

BASIC PARAMETERS

Dimension	[illegible]
Net Weight	[illegible]
Pod Capacity	[illegible]
Battery	[illegible]
Battery Voltage	[illegible]
Output Voltage	[illegible]
Power Range	[illegible]
Charging Voltage	[illegible]
Coil Resistance Supported	[illegible]
Display	[illegible]
Body Material	[illegible]

COMPONENTS OVERVIEW

OPERATION STEPS

Step 1. Install the battery

Step 2. Install coil

Step 3. Fill e-liquid

Step 4. Install the pod

Step 5. Start use the device

BASIC OPERATION

WARNING DESCRIPTION

Anti-reversed Protection:

Battery Reminder:

Low Battery:

Power-off Memory Function:

Check Atomizer:

Short Circuit:

Too Hot:

Over 10s:

PERINGATAN KESELAMATAN

FITUR UTAMA

PARAMETER DASAR

GAMBARAN UMUM KOMPONEN

LANGKAH OPERASI

OPERASI DASAR

DESKRIPSI PERINGATAN

AVERTISSEMENTS DE SÉCURITÉ:

CARACTÉRISTIQUE PRINCIPALE

PARAMÈTRE FONDAMENTAUX

VUE D'ENSEMBLE DES COMPOSANTS

ÉTAPES DE FONCTIONNEMENT

OPÉRATION DE BASE

DESCRIPTION DE L'AVERTISSEMENT

OSTRZEŻENIA DOTYCZĄCE BEZPIECZEŃSTWA

GŁÓWNA CECHA

PARAMETRY PODSTAWOWE

PRZEGLĄD KOMPONENTÓW

KROKI OPERACYJNE

PODSTAWOWA OPERACJA

OPIS OSTRZEŻENIA

AVVERTENZE DI SICUREZZA

CARATTERISTICA PRINCIPALE

PARAMETRI DI BASE

PANORAMICA DEI COMPONENTI

FASI OPERATIVE

OPERAZIONE BASE

DESCRIZIONE DI AVVERTIMENTO

SICHERHEITSWARNUNGEN

HAUPTMERKMAL

GRUNDPARAMETER

KOMPONENTENÜBERSICHT

BETRIEBSSCHRITTE

GRUNDBETRIEB

BESCHREIBUNG DER WARNUNG

ADVERTENCIAS DE SEGURIDAD

CARACTERÍSTICA PRINCIPAL

PARÁMETROS BÁSICOS

DESCRIPCIÓN GENERAL DE LOS COMPONENTES

PASOS DE LA OPERACIÓN

OPERACIÓN BÁSICA

DESCRIPCIÓN DE ADVERTENCIA

ПРЕДОСТЕРЕЖЕНИЕ ПО ТЕХНИКЕ БЕЗОПАСНОСТИ

ГЛАВНАЯ ОСОБЕННОСТЬ

ОСНОВНЫЕ ПАРАМЕТРЫ

ОБЗОР КОМПОНЕНТОВ

ЭТАПЫ ЭКСПЛУАТАЦИИ

ОСНОВНАЯ ОПЕРАЦИЯ

ПРЕДУПРЕЖДЕНИЕ ОПИСАНИЕ